


CLIP FAN

User manual

**zam
nesia.**

**Thank you for
being a fan of
our products**



Team Zamnesia



Information


You have chosen the Zamnesia Clip Fan. Designed for efficient air circulation within your grow tent, this compact 6-inch (15.2cm) fan provides steady airflow to maintain optimal temperature and humidity. Built with durable materials and a secure grip clip, it ensures consistent performance while saving valuable grow space.

Please read this manual carefully before use to ensure safe operation and optimal performance. Following the instructions will help extend the lifespan of your fan and maintain a healthy growing environment.


Manual index

- 04** Information
- 06** - What's in the box
- Specifications
- 07** Operating instructions
- 08** Installation
- 10** Connect to your Grow Environment Controller
- 11** Maintenance and cleaning
Troubleshooting
- 12** Safety/warnings


What's in the box



1x Fan head



1x Clip



1x Fixing screw



1x Control cable

6

Specifications

Feature	Details
Fan blade size	6 inch (152mm)
Voltage	100–240V AC, 50/60Hz
Power	10W
Speed	2500 RPM
Air volume	330 CFM
Noise level	32 dBA
Tilt range	120° (up-down adjustable)
Grip range	Fits 15–30mm grow tent poles
Weight	0.6 kg

Operating instructions

Modes below are controlled using the ON/OFF button:



Power ON/OFF

Press once to turn the Clip Fan ON.
Hold the button for 3 seconds to turn Clip Fan OFF.

Speed mode

When switched ON, short-press the power button to cycle through 1–10 speed levels. Each level is indicated by a corresponding light on the back around the power button.

Cycle mode

Double-press the power button to enable automatic speed cycling, using the currently selected speed. For example (levels 1–7, then 7–1).



USB type-C mode (if applicable)


When connected via Type-C to a compatible master controller, the Clip Fan's speed is controlled externally.
Manual button operation is disabled in this mode.

7


Installation

- 1 Before setting up**
Ensure the fan is disconnected from power before setup.

The clip base allows 360° rotation. Rotate the fan head to the desired direction before installation.




- 2 Attach the clip to tent pole**
Attach the clip securely to a tent pole (15–30mm).




- 3 Lock the fan in place**
Tighten the fixing screw to lock the angle and tilt in place. Confirm that the fan is positioned securely and not obstructed by plants or tent walls.

- 4 Connect to power**
Plug the fan into a suitable power outlet and turn it on.




Connect to your Grow Environment Controller

1 Locate the cable opening beneath the controller mounting position.



2 Feed the fan cable through the opening from inside the grow tent to the outside.



3 Connect the cable to the controller by plugging it into **OUT2 (Clip Fan)**.

4 Secure excess cable to keep it clear of moving parts and airflow.

Maintenance and cleaning

- Always disconnect the fan from power before cleaning.
- Do not submerge the fan or spray water directly on it.
- Wipe the fan housing and blades gently using a slightly damp sponge or soft cloth.
- Make sure the fan is completely dry before reconnecting to power.

Troubleshooting

Issue	Possible Cause	Solution
Fan doesn't start	Power not connected / switched off	Check outlet, plug, and power button
Weak airflow	Speed setting too low	Increase speed level
Fan vibrates or rattles	Loose clip or fixing screw	Tighten all connections and ensure stable mounting
Fan stops mid-operation	Overheating or obstruction	Unplug, remove blockage, allow to cool

Safety/warnings

- Read all instructions carefully before installation or use.
- Incorrect installation or handling may result in damage, electric shock, personal injury, or fire.
- This product is intended for indoor air circulation use only.
- Do not use outdoors or in environments exposed to moisture, excessive heat, or flammable substances.
- Ensure the fan is securely mounted or clipped before operation.
- Do not insert fingers or objects into the fan guard during operation.
- Always disconnect the product from the power supply before installation, cleaning, or maintenance.
- Do not modify the product or use accessories not specified by the manufacturer.
- Keep the product out of reach of children and persons requiring supervision.
- Dispose of this product in accordance with local waste and WEEE regulations. Do not dispose of with household waste.



Lorentzweg 7
5482 TP Schijndel
the Netherlands
www.zamnesia.com